






Question?
Contact
Philips



- EN Short User Manual
- CS Krátká uživatelská příručka
- DA Kort brugervejledning
- DE Kurzanleitung
- EL Σύντομο εγχειρίδιο χρήσης
- ES Manual de usuario corto
- FI Lyhyt käyttöopas
- FR Bref mode d'emploi
- HU Rövid használati útmutató
- IT Manuale dell'utente breve
- NL Korte gebruikershandleiding
- PL Krótka instrukcja obsługi
- PT Manual do utilizador resumido
- RU Краткое руководство пользователя
- SK Stručný návod na používanie
- SV Kortfattad användarhandbok

PHILIPS



Battery power	LED indicator
Low	Flashing fast
Medium	Flashing slowly
Full	Steadily on

The speaker mute when the battery level is low.

DBB

VOLUME

To get the detailed instructions for use, visit www.philips.com/support.

iPod touch (5th generation)

iPod nano (7th generation)

iPhone 5



