


Exploded view



Parts List

No.	Part name
1	Output Axis
2	Gasket
3	Gearbox
4	Self-lock Inner Ring
5	Self-lock Inner Core
6	Self-lock Block
7	Front Star Gear
8	Middle Star Gear Holder
9	Back Star Gear
10	Big Gasket
11	Motor Holder
12	Motor Gear
13	Motor
14	Switch
15	Shell
16	Led Indicator
17	Light Cover
18	Bulb Light
19	Light Switch
20	Connector Pin
21	PDC
22	Battery
23	Charger Socket
24	Magnet
25	Plastic Label